



YVSOLAB NV
Veedijk 33
2300 TURNHOUT
BELGIUM



Tel:+32 (0)14/67 27 79
Fax:+32 (0)14/55 77 68
E-mail: info@yvsolab.be
Website: www.yvsolab.be

Ethades

Product code 00311

Unique ready-to-use product suitable for disinfecting the skin (PT1) and small areas (PT 2 and 4)

Ethades is based on pure ethanol (580 g / l - 73.4% v / v) and dries without. Permitted for use in food processing, healthcare, hospitality, cosmetics industry and laboratories include the hands, kitchen and computer equipment, instruments, furniture, fixtures, cabinets and machines.

Ethades is allowed in the Netherlands with admission number N-14065 and in Belgium under admission number 7315B. Ethades is also registered with baua (D). Product meets the requirements of the Working Party on Infection Prevention (NL), Higher Health Council (B) and World Health Organization.

The efficacy of Ethades has been demonstrated using the following tests:

EN 1040 Pseudomonas Aeruginosa & Staphylococcus Aureus

EN 1276 E. coli, Candida Albicans & Salmonella typhimurium

EN 1500 E. coli praktijktest

EN 13727 E. coli, S. aureus, P.aeruginosa & E. hirae

EN 14476 Murine Norovirus

EN 1275 Candida Albicans & Aspergillus Niger

EN 13697 Salmonella typhimurium

Usage and dosage:

A. For hand disinfection:

- Apply to clean, dry hands.
- Apply 3 ml Ethades to the hands.
- Rub hands for 30 seconds together carefully. The fingertips, thumbs, areas between the fingers and wrists should be thoroughly rubbed on the drug.
- Ensure that hands remain wet during the entire reaction time of 30 seconds.
- Then let your hands dry.

B. Use as disinfectant for small surfaces:

Disinfect surfaces and materials thoroughly cleaned in advance with suitable detergent and then rinse with clean water. Remove excess water. The agent diluted in the surfaces to be disinfected. Use as much liquid (use 40-50 ml of product per m²) that the surfaces remain wet throughout the exposure time.

Minimum exposure time: 30 seconds

Technical features:

Colour: Transparant

Scent: Unscented

pH-value concentrate: 6.5

Packaging:

Box 6 x 1 liter spraybottle (01FL03)

Safety and storage:

For more information regarding storage, transportation and safety we refer you to the Safety Data Sheet. Use the disinfectant safely. Always read the product information and label before use.

Disinfection

